

## Evener WoodWall.

### Primer and Adhesive Combinations

This table shows combinations of primer and adhesive that have, under test conditions, provided an excellent bond between Evener WoodWall and the nominated substrate.

APPLICATION	PRIMER	ADHESIVE	NOTES
New Plasterboard Walls	GARDZ	ROMAN PRO 774	Non Strippable
		ROMAN PRO 111 <sup>1</sup>	Non Strippable
		ROMAN PRO 555	Non Strippable
	ROMAN PRO 935	ROMAN PRO 774	Non Strippable
		ROMAN PRO 732	
		ROMAN PRO 111	
		ROMAN PRO 555	
	ROMAN PRO 977	ROMAN PRO 774	Non Strippable
		ROMAN PRO 732	
		ROMAN PRO 111	
ROMAN PRO 555			
	TITEBOND II <sup>2</sup>	Non Strippable	
TITEBOND II	TITEBOND II <sup>2</sup>	Non Strippable	
Painted Plasterboard	ROMAN PRO 977	ROMAN PRO 732	Non Strippable
		ROMAN PRO 111	Non Strippable
		ROMAN PRO 555	Non Strippable
Existing Damaged Plasterboard	GARDZ	ROMAN PRO 111	
		ROMAN PRO 555	
MDF	BULL'S EYE 1.2.3.	ROMAN PRO 111	Non Strippable
	KILZ PREMIUM		Non Strippable
	SHERWIN WILLIAMS EXTREME BOND		Non Strippable
Galvanised Steel Door		3M HI STRENGTH 90	

1. BEST ALLROUNDER

2. Size back of sheet with 1/10 strength Titebond for 24 hrs then use full strength as adhesive, or size at full strength and book as normal, or no size just full strength for adhesive.

