

STOPGAP Pen

Technical Data Sheet

MANUFACTURER

Printec GmbH
Auf dem Haderland 10
D-99894 Friedrichroda, OT Ernstroda
+49 (0) 3623 31182 0
+49 (0) 3623 31182 32
msds@printec-gmbh.de
www.printec-gmbh.de

FUNCTION

Every substrate has certain asperities in which dirt, mold and other contaminants can accumulate. STOPGAP PEN fills gaps and irregularities and thus offers perfect protection against water, dirt and steam.

APPLICATION

First remove the pen cap and then place its sponge on the surface. Slightly pull the pen along the desired area to apply the fluid. Close the cap right after use in order to prevent the sponge from drying out.

CLEANSING

During product application it may occur that more fluid than required will be applied. In this case, the excess fluid should be carefully wiped off with a clean microfiber cloth.

STORAGE CONDITIONS

The STOPGAP PEN should only be kept in the original pen case in an air-conditioned place. The liquid must also be protected from sunlight, heat and oxygenation. Pens that have already been opened must be stored locked to prevent possible leakage.

DISCLAIMER

Information and advice for application, if orally, in writing or by tests, are to the best of our knowledge, however, are not binding, especially in view of possible third party trade mark rights. Consultation with us does not exempt you from executing your own testing for the planned methods and purposes. Application, use and processing of our products, as well as your manufacturing of final goods following our advice are beyond our control, and thus, lie solely in your responsibility. The sale of our products is carried out according to our general commercial terms and conditions. Indicated data serve for orientation only. They do not represent any specification, nor give warranty for edge banding characteristics.

